

# DANCE KIT

**MODEL**

Dance Kit

**REF. NO.**

P3-48000

**DESCRIPTION**

Single lever washbasin mixer XL with pop-up waste set 1 1/4"

+  
Single lever bath/shower mixer

+  
3-speed hand shower, with 60 cm rail, with 160 cm shower hose & soap dish

**FINISH**

Brass Chrome Plated / ABS

